




Bulova 10CH Movement Parts (1)

Compiled by EmmyWatch - <https://www.emmywatch.com>

10 CH

10 CH



Nº BULOVA		Caliber reference	Nº BULOVA		Caliber reference
1	10 CH	11 AL	70 L	10 CH	11 AF
2	10 CH	11 AL	70 R	10 CH	11 AF
4	10 CH	11 AF	85 A	10 CH	11 AL
5	10 CH	11 AL	86	10 CH	11 AL
6	10 CH	11 AL	111	10 CH	11 AL
7	10 CH	11 AF	112	10 CH	11 AL
8	10 CH	11 AF			
11	10 CH	11 AF			
13	10 CH	11 AL			
14	10 CH	11 AF			
15	10 CH	11 AF			
16	10 CH	11 AF			
17	10 CH	11 AF			
18	10 CH	11 AF			
23	10 CH	11 AL			
24	10 CH	11 AF			
25	10 CH	11 AF			
26	10 CH	11 AF			
28	10 CH	11 AF			
29	10 CH	11 AF			
31	10 CH	11 AL			
32	10 CH	11 AL			
35	10 CH	11 AL			
37-38	10 CH	11 AL			
39	10 CH	11 AF			
40 A	10 CH	11 AL			
41	10 CH	11 AL			
42	10 CH	11 AL			
44	10 CH	11 AF			
47	10 CH	6 BL			
48	10 CH	11 AF			
51	10 CH	11 AL			
53	10 CH	11 AL			
54	10 CH	11 AL			
54 A	10 CH	11 AL			
54 B	10 CH	11 AL			
56	10 CH	11 AL			
57	10 CH	11 AL			
58	10 CH	11 AL			
59	10 CH	11 AL			
60	10 CH	11 AF			
62 A	10 CH	11 AF			
63	10 CH	85			
64	10 CH	140			
65	10 CH	22			