





Bulova 16AC Movement Parts (1)

Compiled by EmmyWatch - <https://www.emmywatch.com>

16 AC



3:1

16 AC

| N° BULOVA | | Caliber reference |
|-----------|----------------------------------------------------------|-------------------|
| 1 | 16 AC | 16 AC |
| 2 | 16 AC | 16 AC |
| 4 | 16 AC | 16 AB |
| 5 | 16 AC | 16 AB |
| 6 | 16 AC | 16 AC |
| 7 | 16 AC | 16 AB |
| 8 | 16 AC | 16 AB |
| 11 | 16 AC | 16 AB |
| 13 | 16 AC | 16 AB |
| 14 | 16 AC | 16 AB |
| 15 | 16 AC | 16 AB |
| 16 | 16 AC | 16 AB |
| 17 | 16 AC | 16 AB |
| 18 | 16 AC | 16 AB |
| 23 | 16 AC | 16 AB |
| 24 | 16 AC | 16 AB |
| 25 | 16 AC | 16 AC |
| 26 | 16 AC | 16 AB |
| 28 | 16 AC | 16 AC |
| 29 | 16 AC | 16 AB |
| 30 A | 16 AC | 16 AB |
| 31 | 16 AC | 16 AB |
| 32 | 16 AC | 16 AB |
| 35 | 16 AC | 16 AB |
| 37-38 | 16 AC | 16 AB |
| 39 | 16 AC | 16 AB |
| 40 | 16 AC | 16 AC |
| 41 | 16 AC | 16 AC |
| 42 | 16 AC | 16 AB |
| 44 | 16 AC | 16 AC |
| 45 | { Page 50, Page 50, Página 50, Seite 50, Pagina 50 | |
| 47 | 16 AC | 16 AB |
| 48 | 16 AC | 16 AB |
| 51 | 16 AC | 16 AB |
| 53 | 16 AC | 16 AB |
| 54 | 16 AC | 16 AB |
| 54 A | 16 AC | 16 AB |
| 54 B | 16 AC | 16 AB |
| 56 | 16 AC | 16 AB |
| 57 | 16 AC | 16 AB |
| 58 | 16 AC | 16 AB |
| 59 | 16 AC | 16 AC |
| 60 | 16 AC | 16 AB |
| 62 A | 16 AC | 16 AB |

| N° BULOVA | | Caliber reference |
|-----------|-------|-------------------|
| 63 | 16 AC | ∅ 100 |
| 64 | 16 AC | ∅ 200 |
| 65 | 16 AC | ∅ 28 |
| 70 L | 16 AC | 16 AB |
| 70 R | 16 AC | 16 AB |
| 85 A | 16 AC | 16 AB |
| 86 | 16 AC | 17 AH |
| 111 | 16 AC | 16 AC |
| 112 | 16 AC | 16 AC |