




**Citizen 9570A,9570B Movement Parts (1)**

*Compiled by EmmyWatch - <https://www.emmywatch.com>*

Catalog No. 957-1



**957-1**  
(Catalog No.)



**957-1**  
(Catalog No.)

**9570 A/B**

- Quartz crystal oscillator type LC digital display
- Time
- Calendar
- Melody Alarm
- Alarm
- Stop watch
- Timer
- Dual time
- Alphabet/figure memory
- 12-24 hour switching
- Illumination Lamp

Thickness: 6.2mm<sup>t</sup>

Size	27mmφ (max. 28mmφ)
Vibrations per second	32,768Hz



Catalog No. 957-1

Parts No.	Name of parts	Caliber No.		Remark
		9570A	9570B	
	Nos. of jewels	00	00	
176	LC display panel holder	40	○	Two units used
211	Reflecting plate	115	108	
☆ 226	Supporter for plate complete	69	○	
☆ 226	LC display panel supporter	152	○	
231	Power cell connector spring	59	○	
235	Light diffusing plate	83	○	
247	Device cover	281	291	
268	LC display panel connection rubber	84	○	Two units used
280	Power cell	15	○	
281	LC display panel	579	○	
☆ 282	Switch spring for correction	11	○	
☆ 282	Switch spring for digit selection	12	○	
☆ 282	Switch spring for lamp	13	○	
750	Plate complete	792	○	
902	Buzzer contact spring	149	○	
924	Screw for LC display panel holder	53	○	Four units used
924	Screw for plate complete supporter	○	○	
761	Power cell strap for checking	012	○	
924	Screw for power cell strap for checking	53	○	

EMMYWATCH  
VINTAGE RESTORATIONS