



EMMYWATCH
VINTAGE RESTORATIONS

Miyota 0S10,0S20,0S30,0S60,0S80 Movement Parts (1)

Compiled by EmmyWatch - <https://www.emmywatch.com>

***** CAL. OS SERIES MOV'T PARTS LIST *****

ORIGINAL PARTS, MADE IN JAPAN

PART NAME	OS10/OS11	OS20	OS30	OS60	OS80
ALARM MARKING WHEEL	-	-	-	-	189-070
ALARM MARKING WHEEL GUARD	-	-	-	-	117-280
BATTERY	280-4405	280-4405	280-4405	280-4405	280-4405
BATTERY CONNECTOR SPRING	231-345	231-345	231-345	231-345	231-371
BUZZER CONTACT SPRING	-	-	-	-	903-201
BUZZER TERMINAL PLATE	-	-	-	-	184-154
CALENDAR CORRECTOR LEVER	116-106	116-115	116-106	116-106	116-115
CALENDAR CORRECTOR WHEEL	213-380	213-440	213-380	213-380	-
CALENDAR PLATE	-	714-069	-	-	-
CANNON PINION WITH DRIVING WHEEL	028-218	028-295	028-218	028-218	028-295
CENTER WHEEL COCK	711-163	711-163	711-163	711-167	711-167
CHRONOGRAPH COIL UNIT 1	246-148	246-148	246-148	246-148	246-148
CHRONOGRAPH COIL UNIT 2	-	-	-	246-178	246-178
CHRONOGRAPH WHEEL	-	-	-	251-090	251-190
CIRCUIT INSULATER	-	-	-	-	233-482
CLUTCH WHEEL	064-670	064-670	064-670	064-670	064-670
COIL UNIT	246-147	246-147	246-147	246-147	246-147
CONTACT SPRING	-	-	-	-	258-390
DATE DIAL	108-A0XX	108-A0XX	108-A0XX	108-A0XX	108-A001
DATE DIAL DRIVING WHEEL	103-105	103-105	-	103-105	103-116
DATE DIAL GUARD (1)	293-990	293-119	-	293-990	293-111
DATE JUMPER	109-580	109-580	-	109-580	109-580
DIAL GUARD	713-107	713-138	-	713-107	-
ELECTRIC CIRCUIT UNIT	279-J17	279-J17	279-J17	279-J39	-
ELECTRIC CIRCUIT UNIT	-	-	-	-	279-B68
FIFTH WHEEL AND PINION	084-640	084-640	084-640	084-640	084-640
FLY-BACK CONNECTION LEVER	270-060	270-060	270-060	270-060	270-060
FLY-BACK LEVER	260-116	260-116	260-116	260-116	260-116
FORTH WHEEL AND PINION	023-267	023-267	023-267	023-267	023-267
HOUR RECORDING WHEEL	294-710	-	294-710	294-710	294-760
HOUR WHEEL	075-392	075-523	075-392	075-392	075-477
INTERMEDIATE CHRONOGRAPH WHEEL	-	-	-	087-141	087-141
INTERMEDIATE DATE WHEEL 1	-	-	-	-	100-590
INTERMEDIATE DATE WHEEL 2	-	-	-	-	100-600
INTERMEDIATE DATE CORRECTING WHEEL	087-620	087-620	087-620	087-620	087-620
INTERMEDIATE DATE CORRECTING WHEEL(1)	-	087-217	-	-	-
INTERMEDIATE DATE CORRECTING WHEEL(2)(3)	-	087-218	-	-	-
INTERMEDIATE DATE CORRECTING WHEEL(4)	-	087-219	-	-	-
INTERMEDIATE FLY-BACK WHEEL	-	087-216	-	-	-
INTERMEDIATE HOUR-RECORDING WHEEL 1	087-135	-	087-135	087-135	087-135
INTERMEDIATE HOUR-RECORDING WHEEL 2	087-136	-	087-136	087-136	087-136
INTERMEDIATE HOUR-RECORDING WHEEL 3	087-137	-	087-137	087-137	087-137
INTERMEDIATE MINUTE WHEEL	087-138	087-138	087-138	087-138	087-138
INTERMEDIATE MINUTE-RECORDING WHEEL	087-134	087-135	087-134	087-134	087-134
INTERMEDIATE MINUTE-RECORDING WHEEL(2)	-	087-214	-	-	-
INTERMEDIATE MINUTE-RECORDING WHEEL(3)	-	087-215	-	-	-
INTERMEDIATE SECOND-RECORDING WHEEL	087-221	087-221	087-221	087-221	087-221
INTERMEDIATE UNLOCKING CORR. WHEEL	-	-	-	-	213-450
MINUTE RECORDING WHEEL	291-060	291-090	291-060	291-060	291-070
MINUTE WHEEL AND PINION	072-114	072-114	072-114	072-114	072-114
ROCKING BAR	-	-	-	-	165-410
ROTOR	285-223	285-223	285-223	285-223	285-223
ROTOR FOR CHRONOGRAPH	285-224	285-224	285-224	285-224	285-224
ROTOR FOR SECOND CHRONOGRAPH	-	-	-	285-151	285-151
SCREW FOR CENTER WHEEL COCK (X3)	923-980	923-980	923-980	923-980	923-980
SCREW FOR CHRONOGRAPH COIL UNIT 1	923-990	923-990	923-990	923-990	923-990
SCREW FOR CHRONOGRAPH COIL UNIT 2(X2)	-	-	-	923-990	923-990
SCREW FOR CHRONOGRAPH GURD(X4)	923-980	923-980	923-980	923-980	923-980
SCREW FOR COIL UNIT	923-990	923-990	923-990	923-990	923-990
SCREW FOR DATE DIAL GUARD (X3)	929-480	929-640	-	929-480	929-630
SCREW FOR ELECTRIC CIRCUIT (X2)	923-990	923-990	923-990	923-990	923-990
SCREW FOR TRAIN WHEEL BRIDGE (X3)	923-980	923-980	923-980	923-980	923-980
SECOND CHRONOGRAPH WHEEL	251-080	251-180	251-080	251-080	251-180
SECOND WHEEL	025-950	025-114	025-950	-	-

SETTING LEVER	067-993	067-993	067-993	067-993	067-993
SETTING STEM	065-453	065-453	065-453	065-453	065-453
SETTING WHEEL	076-680	076-680	076-680	076-680	076-680
SPACER FOR ELECTRIC CIRCUIT 1 (X2)	027-111	027-111	027-111	-	-
SPACER FOR ELECTRIC CIRCUIT 1 (X3)	-	-	-	027-111	027-111
SPACER FOR ELECTRIC CIRCUIT 2	027-112	027-112	027-112	027-112	027-112
SPACER FOR SETTING STEM	212-A54	212-A54	212-A54	212-A54	212-256
STATOR	190-126	190-126	190-126	190-126	190-126
STATOR FOR CHRONOGRAPH 1	190-128	190-128	190-128	190-128	190-128
STATOR FOR CHRONOGRAPH 2	-	-	-	190-131	190-131
STOP LEVER	204-530	204-530	204-530	204-530	204-530
SUPPORTER FOR PLATE COMPLETE	226-497	226-497	226-497	226-497	226-459
SUPPORTOR FOR CHRONOGRAPH PLATE	720-203	720-526	720-204	720-209	720-448
SWITCH LEVER ACTUATING SPRING	-	-	-	-	282-920
SWITCH SPRING FOR ALARM	-	-	-	-	227-580
SWITCH STEM FOR ALARM	-	-	-	-	065-513
24 HOUR DRIVING WHEEL	-	100-670	-	-	-
THIRD WHEEL AND PINION	017-142	017-142	017-142	017-142	017-142
TRAIN WHEEL BRIDGE	701-E92	701-E92	701-E92	701-E92	701-875
UNLOCKING CORRECTING WHEEL	-	-	-	-	213-450
UNLOCKING LEAD PLATE	-	-	-	-	184-155
UNLOCKING WHEEL	-	-	-	-	169-070
YOKE	071-128	071-128	071-128	071-128	071-128
LONG SETTING STEM(24.00MM - the length of the thread 10mm)	065-557	065-557	065-557	065-557	065-557
LONG SETTING STEM(24.00MM - the length of the thread 5.3mm)	(065-533)	(065-533)	(065-533)	(065-533)	(065-533)

EMMYWATCH
VINTAGE RESTORATIONS