




**Rolex 1055,1055B Movement Parts (1)**

*Compiled by EmmyWatch - <https://www.emmywatch.com>*

# Calibre 1055 & 1055B


Base Calibre 1030

- Ø28.5mm
- Train: 18.000
- Automatic
- Date & day of the week
- Sweep second
- Shock Proof



1 : 1

## 1055



7120



7122



7121



7123



7125



7126



7127



7128



7130



7131



7132



7134



7135



7136



7138



7139



7141



7142

EMMYWATCH  
VINTAGE RESTORATIONS



7143



7145



7146



7152



8017

2 : 1



7133



7137



7140



7147



7999

1 : 1

## 1055 B




7155 B



7157 B



7158 B



7161 B

2 : 1



7156 B



7159 B

|      |             |   |      |               |   |
|------|-------------|---|------|---------------|---|
|      | <b>7120</b> | <i>Plate</i>  |      | <b>7147</b>   | <i>Set of screws for<br/>1 watch movement</i> |
|      | <b>7121</b> | <i>Center wheel with<br/>cannon pinion</i>                          |      |               |   |
| 1040 | <b>7122</b> | <i>Balance cock</i>   | 1555 | <b>7152</b>   | <i>Bridle</i>                                 |
| 1040 | <b>7123</b> | <i>Balance with<br/>Breguet hairspring,<br/>regulated</i>           | 1555 | <b>7155 B</b> | <i>Star impulse finger</i>                    |
|      | <b>7125</b> | <i>Cannon pinion,<br/>height 3,40 mm</i>                            |      | <b>7156 B</b> | <i>Screw for : Star<br/>impulse finger</i>    |
|      | <b>7126</b> | <i>Sweep-second<br/>pinion</i>                                      |      | <b>7157 B</b> | <i>Date jumper</i>                            |
| 1040 | <b>7127</b> | <i>« Rolex Shock-<br/>resisting » device<br/>for balance, upper</i> |      | <b>7158 B</b> | <i>Day check-spring</i>                       |
|      | <b>7128</b> | <i>Bridge for self-<br/>winding mechanism</i>                       |      | <b>7159 B</b> | <i>Set of screws for<br/>1 watch movement</i> |
|      | <b>7130</b> | <i>Double tothing<br/>hour wheel,<br/>height 2,46 mm</i>            | 1555 | <b>7161 B</b> | <i>Calendar ring,<br/>ref. 6611</i>           |
| 1036 | <b>7131</b> | <i>Calendar yoke</i>  | 1555 | <b>7999</b>   | <i>Screw for : Bridle</i>                     |
|      | <b>7132</b> | <i>Calendar yoke<br/>spring</i>                                     |      | <b>8017</b>   | <i>Day disc</i>                               |
|      | <b>7133</b> | <i>Screw for : Calendar<br/>yoke spring</i>                         |      |               |   |
|      | <b>7134</b> | <i>Cam with cannon</i>  |      |               |   |
| 1555 | <b>7135</b> | <i>Calendar wheel</i>   |      |               |   |
|      | <b>7136</b> | <i>Star impulse finger</i>  |      |               |   |
|      | <b>7137</b> | <i>Screw for : Star<br/>impulse finger</i>                          |      |               |   |
|      | <b>7138</b> | <i>Date jumper</i>  |      |               |   |
|      | <b>7139</b> | <i>Day check-spring</i>   |      |               |   |
|      | <b>7140</b> | <i>Screw for : Day<br/>check-spring</i>                             |      |               |   |
| 1555 | <b>7141</b> | <i>Star unit</i>  |      |               |   |
|      | <b>7142</b> | <i>Calendar ring,<br/>ref. 6511</i>                                 |      |               |   |
|      | <b>7143</b> | <i>Calendar ring,<br/>ref. 6611</i>                                 |      |               |   |
|      | <b>7145</b> | <i>Date disc</i>  |      |               |   |
|      | <b>7146</b> | <i>Complete rotor</i>   |      |               |   |

EMMYWATCH  
VINTAGE RESTORATIONS