



EMMYWATCH
VINTAGE RESTORATIONS

Rolex 1130 Movement Parts (1)

Compiled by EmmyWatch - <https://www.emmywatch.com>

Calibre 1130

Ø20.00mm
Ht: .405mm
Train: 19.800

- Automatic
- Small second
- Shock Proof
- 26 Jewels

Base Calibre 1120









Image	Rolex No.	Description
	129	Bridle
	171	Screw for bridle
	6667	Main plate
	6669	Train wheel bridge
	6670	Centre wheel with cannon pinion
	6671	Third wheel
	6672	Jewel for third wheel-upper
	6673	Second wheel














Image	Rolex No.	Description
	6675	Driving wheel over third wheel
	6676	Centre second pinion
	6677	Second pinion friction spring
	6678	Screw for second pinion friction spring
	6730	Automatic device upper bridge
	6731	Foot for automatic device upper bridge
	6732	Bearing pad for oscillating weight
	6733	Automatic device lower bridge
	6735	Oscillating weight
	6736	Axle for oscillating weight
	6737	Winding wheel
	6738	Oscillating weight bolt-axle
	6739	Spring-clip

Image	Rolex No.	Description
	6740	Intermediate wheel n°2
	6741	Bush for reversing wheel-lower
	6744	Automatic device module
	6745	Enlargement ring
	6748	Set of screws

EMMYWATCH
VINTAGE RESTORATIONS