



EMMYWATCH
VINTAGE RESTORATIONS

Rolex 1300 Movement Parts (1)

Compiled by EmmyWatch - <https://www.emmywatch.com>

Calibre 1300

Ø17.80x15.30mm • Without second
 Ht: 3.48mm • Shock Proof
 Train: 18.000 • 17 Jewels

Base Calibre 1300









Image	Rolex No.	Description
	1843	Screw for crown wheel core
	1878	Spring for in-setting for escape wheel-upper /lower
	2926	Screw for pallet bridge
.	2941-1	Adjusting washer: 1/100
	2941-2	2/100
	2941-3	3/100
	2941-4	4/100
	2941-5	5/100
	4465	Friction spring for hour wheel
	6607	Jewel for: • Third wheel-upper • Second wheel-upper
	6608	Jewel for: • Third wheel-lower • Second wheel-lower
	6619-1	Jewel for pallet fork-upper /lower
	6760	In-setting for escape wheel-upper /lower












Image	Rolex No.	Description
	7690	Main plate
	7691	Barrel bridge
	7692	Train wheel bridge
	7700	Mainspring, strength standard
	7700-1	Mainspring, strength weak
	7701	Barrel arbor
	7702	Barrel with arbor
	7704	Centre wheel with cannon pinion
	7705	Bush for centre wheel-upper
	7706	Third wheel
	7709	Second wheel
	7712	Escape wheel
































Image	Rolex No.	Description
	7713	Pallet bridge
	7715	Pallet fork
	7715-1	Banking pin
	7716	Pallet staff
	7718	Entry pallet
	7719	Exit pallet
	7722	Balance bridge
	7723	Screw for balance bridge
	7725	Balance with flat hairspring, timed
	7726	Screw for balance
	7727	Screw for regulating the balance
	7733	Balance staff
	7734	Roller
	7736	Regulator
	7737	Winding stem
	7738	Winding pinion

Image	Rolex No.	Description
	7739	Sliding pinion
	7740	Crown wheel
	7741	Crown wheel core
	7742	Crown wheel seating
	7744	Ratchet wheel
	7746	Click
	7747	Screw for click
	7748	Spring for click
	7749	Setting lever
	7750	Screw for setting lever
	7751	Jumper for setting lever
	7752	Screw for setting lever jumper
	7753	Yoke for sliding pinion
	7753-1	Yoke stud
	7754	Spring for yoke
	7755	Setting wheel

Image	Rolex No.	Description
	7756	Minute wheel
	7756-1	Stud for minute wheel
	7757	Cannon pinion
	7758	Hour wheel
	7759	Screw for dial
	7760	Screw for: • Barrel bridge • Train wheel bridge
	7760-1	Screw for: • Barrel bridge • Train wheel bridge-thick thread
	7761	Set of screws
	7770	Shock-absorber for balance-upper
	7771	Shock-absorber for balance-lower
	7863	Screw for stud
	7934	Spring with axle for in-setting for balance-upper /lower
	54445	Screw for ratchet wheel
	95019-2	In-setting for balance-upper / lower
	95019-3	Cap jewel for: • Escape wheel-upper /lower • Balance-upper /lower