



EMMYWATCH
VINTAGE RESTORATIONS

Rolex 1520 Movement Parts (1)

Compiled by EmmyWatch - <https://www.emmywatch.com>

Calibre 1520

Ø28.50mm
Ht: 5.75mm
Train: 19.800

- Automatic
- Centre Seconds
- Shock Proof
- 26 Jewels

Base Calibre 1530








Image	Rolex No.	Description
	7825	Mainspring, strength weak
 	8050	Second wheel
	8051	Escape wheel, 26 jewels
	8052	Escape wheel, 17 jewels
	8053	Balance bridge
	8055	Balance with Breguet hairspring, timed
















Image	Rolex No.	Description
	8056-1	Inertia-block, gilt
	8056-2	Inertia-block, nickel-plated
	8057-1	Adjusting washer: 1/100
	8057-2	2/100
	8057-3	3/100
	8057-4	4/100
	8057-5	5/100
	8061	Regulator
	8062	Stud support
	8063	Screw for stud holder
	8064	Automatic device upper bridge
	8065	Shock-absorber for balance-upper
	8066	Automatic device module
	8067	Set of screws

Image	Rolex No.	Description
	8069	Mainspring, strength standard
	8073	Balance stop spring
	8074	Screw for balance stop spring
	8075	Main plate
	8076	Bush for center wheel-lower
	55051	Screw for stud